

1

Prepare The Area

Measure the area to determine the exact placement of your letters or graphics. Make sure the area is clean and free of dust by wiping the surface with a clean dry cloth.

Note: Rounded letters are designed to be slightly larger overall. Therefore, they do extend below the baseline. Proper alignment will be indicated on the spacing tape. Place the rounded letter along the arced line on the spacing tape.

2

Attach The Spacing Tape

Hold the spacing tape in place and tape both ends. Adjust the spacing tape if necessary making sure it is straight. Secure it with additional tape to prevent movement.



3

Position Letters or Graphics

The spacing tape provides a baseline indication for proper placement of each element. Remove any backing from the adhesive and gently place the elements in their respective locations above the spacing tape. Apply light pressure to ensure a secure bond.



4

Remove The Spacing Tape

Begin at one of the top corners and gently guide the spacing tape away from the baseline of the letters, removing tape as you go.



800-354-2102

AdMart
CUSTOM SIGNAGE

PO Box 68
20 Gose Pike
Danville, Kentucky 40423-0068
(859)236-7600, Fax(859)236-9050
mail@admart.com
www.admart.com